

3. Dimensions

AMNW-GSJL0 [DM-RP NSJ] / AMNW-GSJA0 [PM-EP NSJ] / AMNW-GSJB0 [PM-SP NSJ]
 ASNW-GJ1Z0 [DM-RP NSJ] / USNW-GJ3A0 [PM-EP NSJ] / USNW-GJ2F0 [PM-SP NSJ]

